



Size: 105x148mm±0.5mm, 80g书写纸, 黑白正反印刷






FN12A-Q1B-R

120MM ARGB COOLING FAN USER MANUAL

Connect the 4-pin fan PWM connector to CPU_FAN socket on the motherboard.



Connect the fan to the 5V ARGB socket on the motherboard.



Connect the 4-pin fan PWM connector to CPU_FAN socket on the motherboard.

Please verify the amps of the fan header on the motherboard prior to connecting a series of fans to it. If the fan header is rated at 1A, a maximum of 3 fans can be utilized with that series.



POWER UP WITH GAMEMAX

www.gamemaxpc.com