


Size: 105x148mm±0.5mm, 80g书写纸, 黑白正反印刷



TORNADO T12 BK

120MM COOLING FAN USER MANUAL



×1




×4

Connect the 4-pin fan PWM connector to CPU_FAN socket on the motherboard.

4pin PWM Fan
Male Connector






4pin PWM Fan
Female Connector



CAUTION

Please do not plug in the wrong power interface, otherwise it will burn out equipment!



Connect the 4-pin fan PWM connector to CPU_FAN socket on the motherboard.

Please verify the amps of the fan header on the motherboard prior to connecting a series of fans to it. If the fan header is rated at 1A, a maximum of 3 fans can be utilized with that series.



POWER UP WITH GAMEMAX

www.gamemaxpc.com